Technical Service BULLETIN

December 7, 2007

SPEAKER GRILLES ON REAR PACKAGE TRAY CRACKING

Models:

'02 - '06 Camry



Introduction

Some 2002 – 2006 model year Camry customers may complain that the speaker grilles on the rear package tray may be cracking. Use the following repair procedure to correct this condition.

Applicable Vehicles

• 2002 – 2006 model year Camry vehicles.

Parts Information

| CURRENT PART NUMBER | PART NAME | QTY |
|---------------------|--------------------------------|-----|
| 04007-521AA-B0 | Grille, Replacement SSP (Gray) | 1 |
| 04007-521AA-E0 | Grille, Replacement SSP (Oak) | 1 |

NOTE:

A repair kit consisting of just the speaker grilles and some fasteners has been made available to correct this condition (One repair kit contains material to replace both speaker grilles [LH & RH grille and 10 push nuts]).

Warranty Information

| OP CODE | DESCRIPTION | TIME | OFP | T1 | T2 |
|---------|-----------------------------------|------|----------------|----|----|
| BO7002 | Install Speaker Grille Repair Kit | 0.7 | 64330-AA160-#1 | 67 | 12 |

Applicable Warranty*:

This repair is covered under the Toyota Comprehensive Warranty. This warranty is in effect for 36 months or 36,000 miles, whichever occurs first, from the vehicle's in-service date.


^{*} Warranty application is limited to correction of a problem based upon a customer's specific complaint.

Disassembly Procedure


- Remove the rear seat cushion assembly.
 Refer to the Technical Information System (TIS), 2002 2006 model year Camry Repair Manual, Vehicle Interior – Rear Seat – "Rear Seat – Overhaul".
- 2. Remove the roof side garnish inner RH (without curtain shield airbag).
 - A. Using a screwdriver, remove the roof side garnish inner.

HINT:


Tape the screwdriver tip before use.



- 3. Remove the roof side garnish inner LH (without curtain shield airbag).
- 4. Remove the roof side garnish inner RH (with curtain shield airbag).
 - A. Using a screwdriver, remove the roof side garnish inner cover.
 - B. Remove one bolt behind the cover.




- 5. Remove the roof side garnish inner LH (with curtain shield airbag).
- Remove the center stop lamp assembly.
 Refer to TIS, 2002 2006 model year Camry Repair Manual: Vehicle Interior Lighting – "Center Stop Assembly – Replacement".
- Remove the rear seat shoulder belt cover RH.
 - A. Using a screwdriver, disengage the claws in the front side.
 - B. Pull out the shoulder belt cover to the front side to disengage the claws.
 - C. Pull out the shoulder belt from the slit to remove the shoulder belt cover.




Disassembly Procedure (Continued)

- 8. Remove the rear side seat back assembly RH.
- 9. Remove the rear side seat back assembly LH.
- Remove the room partition board assembly.
 Remove the 9 clips and room partition board.




- 11. Remove the package tray trim panel assembly.
 - A. Remove the 3 bolts and floor anchor of the seat belt.
 - B. Disengage the clips and claws and pull out the belt to remove the package tray trim.



Repair Procedure

From the underside of the package tray, drill out the old speaker grille.
 Use an 8 mm (5/16 inch) drill bit, to drill out the heat-staked speaker grille at the five locations.




2. Install the NEW speaker grille and fasten in place using the push lock nuts provided in the repair kit.


HINT:

Use a small deep socket to push the nuts firmly in place.

NOTE:

Make sure that there are NO gaps between the speaker grille and package tray.





3. Reassemble in reverse order of disassembly.