



**Technical Service
Information Bulletin**

July 6, 2001

Title:

**DIAGNOSTIC TESTER
IMMOBILIZER FUNCTIONS**

Models:

**Applicable ES 330, GS 300, GS 430, GX 470,
LS 430, LX 470, RX 330, & SC 430**

REVISED

SS005-01

SPECIAL SERVICE TOOLS

TSIB REVISION NOTICE:

- August 26, 2005: The model years for each model have been specifically defined in the "Applicable Vehicles" section. The following vehicles have been added to the "Applicable Vehicles" section: ES 330, GS 300, GS 430, and RX 330. The "Required SSTs" section has been updated.
- January 9, 2003: GX 470 and LX 470 have been added to Applicable Vehicles. The "Required SSTs" section has been updated to the current version software. Screen flows revised (screen C and D) in Figures 1 (screen C and D), 2 (screen C), 3 (screen C), 4 (screen C and G), and 9 (screen A).
- The information contained in this TSIB supercedes the original SS005-01. Previous versions of this TSIB should be discarded.

Introduction

The Diagnostic Tester incorporates support for Immobilizer system service. This bulletin covers the following Immobilizer functions available using the Diagnostic Tester:

- Transponder Key Type
- Transponder Code Registration
- Transponder Code Erasure
- Transponder ECU Reset
- Transponder ECU Replacement
- Engine ECU Replacement

NOTE:

The available functions and procedures for the models listed in this TSIB differ slightly from previous models and other Immobilizer systems currently in use on Lexus vehicles.

**Warranty
Information**

OP CODE	DESCRIPTION	TIME	OFF	T1	T2
N/A	Not Applicable to Warranty	-	-	-	-



Applicable Vehicles



MODEL YEAR	MODEL	ENGINE MODEL
2001 & Later	LS 430	3UZ-FE
2002 & Later	SC 430	3UZ-FE
2003 & Later	GX 470	2UZ-FE
	LX 470	
2004 & Later	ES 330	3MZ-FE
	RX 330	
2006	GS 300 (w/o Smart Key)	3GR-FSE
	GS 430 (w/o Smart Key)	3UZ-FE

NOTE:
 Refer to TIS (Technical Information System) for the most current applicable vehicle information.

Parts Information

PREVIOUS PART NUMBER	CURRENT PART NUMBER	PART NAME
N/A	Model Specific	Replacement Transponder Key (Master or Sub)

Required SSTs

ITEM NO.	SPECIAL SERVICE TOOLS (SSTs)	PART NUMBER	QTY	DRW**
1	Lexus Diagnostic Tester Kit* NOTE: • All components from this kit/set are required • 12 Megabyte Diagnostic Tester Program Card (P/N 01002593-005) with version 13.0a Software (or later) is required 	LEX220036	1	8
2	CAN Interface Module Kit* NOTE: • All components from this kit/set are required 	01002744	1	8

* Essential SSTs.

** Refers to drawer number in SST Storage System.

NOTE:
 Additional Diagnostic Tester Kits, CAN Interface Modules, Program Cards, or other SSTs may be ordered by calling SPX/OTC at 1-800-933-8335.

- | | |
|-----------------------------|--|
| Function Description | <ol style="list-style-type: none">1. Transponder Key Type
Before any Immobilizer functions are performed, verify the type of transponder key that you are attempting to use for the service operation. Some functions may only be performed with a registered Master Key.
2. Transponder Code Registration
This function allows the registration of additional transponder keys (Master or Sub) using a registered Master Key.
3. Transponder Code Erasure
This function allows the user to erase all the transponder keys except the registered Master Key used during this function.
4. Transponder ECU Reset
This function allows the registration of a new Master Key even if all original Master Keys are lost. Once the Immobilizer system is reset, all previous registered keys will be erased.
5. Transponder ECU Replacement
When the Transponder ECU is replaced, the transponder keys must be registered to the new ECU, auto registration closed, and ECU communication completed.
6. Engine ECU Replacement
When the Engine ECU is replaced, ECU communication must be completed to synchronize an encrypted security code between the engine and Transponder ECUs. |
|-----------------------------|--|

Operation
Procedure
TRANSPONDER
KEY TYPE

1. Transponder Key Type

Before any Immobilizer functions are performed, verify the type of transponder key that you are attempting to use for the service operation. Some functions may only be performed with a registered Master Key.


A. Insert the current key into the ignition cylinder and turn to the **ON** position.

HINT:
The Immobilizer key blanks are preconfigured as Master or Sub Keys. Master Key blanks cannot be registered as Sub Keys nor can Sub Key blanks be registered as Master Keys. Also, the flat key is now enabled as a full function Master Key that must be registered.

B. Follow the screen flow in Figure 1 to determine the key type.

C. Key type and registration status will be indicated on the Immobilizer data list (Figure 1, screen E).

- “MATCH” = The key in the ignition cylinder matches this key type.
- “NOMATCH” = The key in the ignition cylinder does NOT match this key type.



Operation
Procedure
(Continued)
TRANSPONDER
CODE
REGISTRATION

2. Transponder Code Registration

This function allows the normal registration of additional transponder keys (Master or Sub) using a registered Master Key.

NOTE:

This function requires the use of one registered Master Key. The use of a Sub Key will NOT complete Transponder Code Registration. Attempting registration of additional keys with only a Sub Key will result in errors and incomplete registration.

HINT:


The Immobilizer key blanks are preconfigured as Master or Sub Keys. Master Key blanks cannot be registered as Sub Keys nor can Sub Key blanks be registered as Master Keys. Also, the flat key is now enabled as a full function Master Key that must be registered.

- A. Insert a registered Master Key into the ignition cylinder and turn to the **ON** position.
- B. Follow the screen flow in Figure 2 to register new Master or Sub keys. It is possible to register up to 5 Master Keys and 3 Sub Keys.
- C. Be sure to follow the instructions on key insertion, ignition ON/OFF and key removal exactly as described on the Diagnostic Tester.

HINT:


The security indicator light reveals the following information:

- Always ON and NO key in IG* = Transponder ECU in Auto Registration mode
- Blinking and NO key in IG = Normal operation
- Blinking Code 21 = Transponder Code Registration failed
- Blinking Code 22 = Attempt was made to register an already registered Transponder Code



* Immediately after the transponder ECU is installed, the security indicator will blink.

Operation Procedure
(Continued)
TRANSPONDER CODE REGISTRATION



Operation Procedure
(Continued)
TRANSPONDER CODE ERASURE


3. Transponder Code Erasure

This function allows the user to erase all the transponder keys except the registered Master Key used during this function.

NOTE:

This function requires the use of one registered Master Key. The use of a Sub Key will NOT complete Transponder Code Erasure.

- A. Insert a registered Master Key into the ignition cylinder and turn to the **ON** position.
- B. Follow the screen flow in Figure 3 below to erase all Master or Sub keys, except the registered Master Key used for this procedure.



**Operation
Procedure**
(Continued)
**TRANSPONDER
ECU RESET**

4. Transponder ECU Reset

This function allows the registration of a new Master Key even if all original Master Keys are lost. Once the Immobilizer system is reset, all previous registered keys will be erased. Use a new transponder Master Key to complete Transponder ECU Reset.


Immobilizer Reset

The Immobilizer Reset function is a 4-step process:

- A. Using the Diagnostic Tester, retrieve a “Seed Number” through the **OBD/MOBD Immobilizer** function.
 - A “Seed Number” is a unique number provided by the Diagnostic Tester and validated at TMS in order to return a Passcode.
- B. Using the TIS (Technical Information System) workstation, select **Immobilizer Reset**, and complete the request form to retrieve a “Passcode Number.”
 - A “Passcode Number” is a unique number required by the Diagnostic Tester to reset the ECU allowing it to accept a new Master Key.
- C. Enter the “Passcode Number” received from TIS into the Diagnostic Tester, register any additional customer keys, and close auto registration mode.
- D. Confirm successful Immobilizer reset and new Master Key registration.

Operation Procedure
(Continued)
TRANSPONDER ECU RESET


- A. Connect the Diagnostic Tester to DLC3 and turn ignition **ON**.
 - a. Using the Diagnostic Tester, retrieve a “Seed Number” through the **OBD/MOBD Immobilizer** function.
 - b. Follow each step outlined in Figure 4.



Operation Procedure
(Continued)
TRANSPONDER ECU RESET


- B. Using the TIS workstation, select **Immobilizer Reset**, and complete the request form to retrieve a “Passcode Number.”
 - a. Click on **Diagnostics**.
 - b. Click on **Immobilizer Reset**.

FIGURE 5. SELECTING IMMOBILIZER RESET ON TIS



- c. Read the instructions on the screen and click on **Continue**.
(See Figure 6 below.)


FIGURE 6. IMMOBILIZER RESET INSTRUCTIONS ON TIS



Operation Procedure
(Continued)
TRANSPONDER ECU RESET


d. Complete the request form and enter the “Seed Number” from the Diagnostic Tester. Click on **Submit** (Figure 7).

NOTE:
All fields must be completed.



e. TIS will now return the Passcode that needs to be entered into the Diagnostic Tester.

NOTE:
The Passcode given by TIS is only valid for one Immobilizer Reset Event.




**Operation
Procedure**
(Continued)
**TRANSPONDER
ECU RESET**

- C. Using the numbered keys (0–9) on the Diagnostic Tester, enter the “Passcode Number” received from TIS into the Diagnostic Tester (see Figure 9 below). Press **ENTER** to clear all registered transponder codes except the Master key in the ignition cylinder.

NOTE:

- During the reset process do not remove the key from the ignition.
- This step takes approximately 16 minutes.



- Following a reset, the Transponder ECU is in auto registration mode.
- Auto registration mode allows 3 Master Keys and one Sub Key to register automatically.
- To register additional keys, remove the Master Key currently in the ignition. Insert keys (Master or Sub) into the ignition cylinder without turning the ignition on or off – simply insert and remove. (See Figure 9, screen D.)

NOTE:

- If 4 keys are registered at this time, auto registration mode is automatically closed.
- If less than 4 keys are registered at this time, auto registration mode must be closed manually by cycling the ignition ON/OFF more than 5 times in 10 seconds. (See Figure 9, screen E.)
- If more than 4 keys need to be registered, use Transponder Code Registration.

**Operation
Procedure**
(Continued)

**TRANSPONDER
ECU RESET**

- D. Verify that keys are registered correctly by starting the engine with each newly registered key.

NOTE:

- If the vehicle starts, the new key code was registered correctly.
- If the vehicle does not start with any key, perform the Immobilizer Reset function again.
- If only one of the registered keys will not start the vehicle, attempt to register the key again following the Transponder Code Registration procedure (page 5 of this bulletin).

**TRANSPONDER
ECU
REPLACEMENT**

5. Transponder ECU Replacement

When the Transponder ECU is replaced, the transponder keys must be registered, auto registration closed, and ECU communication completed.

- A. Replacement transponder ECUs are in auto registration mode. This allows transponder keys to automatically register as they are inserted into the ignition cylinder. It is possible to automatically register 3 Master Keys, and 1 Sub Key.


NOTE:

- If 4 keys are registered at this time, auto registration mode is closed.
- If less than 4 keys are registered at this time, auto registration mode must be closed manually by cycling the ignition ON/OFF more than 5 times in 10 seconds.
- If more than 4 keys need to be registered, use Transponder Code Registration procedure (page 5 of this bulletin).

- B. Once auto registration mode is closed, ECU Communication must be performed between the transponder ECU and the Engine ECU. Complete ECU communication using the following steps:
- Insert registered Master Key into the ignition cylinder.
 - Turn ignition ON (engine OFF).
 - Short Tc and CG terminals of DLC3 using Diagnosis Check Wire (SST 09843–18040 or equivalent) and leave for 30 minutes. (See Figure 10.)

FIGURE 10. DLC3

Tc = Pin 13
CG = Pin 4



View of Connector Is From Passenger Compartment

- After 30 minutes, turn ignition OFF and remove check wire from DLC3
- Start the vehicle to confirm successful ECU communication.

NOTE:


If ECU communication is not completed correctly, the engine will not start and DTC B2799 will be set. DTC B2799 will be cleared after engine starts correctly.

Operation Procedure
(Continued)
TRANSPONDER ECU REPLACEMENT

HINT:

The security indicator light reveals the following information:

- Always ON and NO key in IG* = Transponder ECU in Auto Registration mode
- Blinking and NO key in IG = Normal operation
- Blinking Code 21 = Transponder Code Registration failed
- Blinking Code 22 = Attempt was made to register an already registered Transponder Code



* Immediately after the transponder ECU is installed, the security indicator will blink.

ENGINE ECU REPLACEMENT


6. Engine ECU Replacement

When the Engine ECU is replaced, ECU communication must be completed. ECU Communication must be performed between the transponder ECU and the Engine ECU. Complete ECU communication using the following steps:

- A. Insert registered Master Key into the ignition cylinder.
- B. Turn ignition ON (engine OFF).
- C. Short Tc and CG terminals of DLC3 using Diagnosis Check Wire (SST 09843–18040 or equivalent) and leave for 30 minutes. (See Figure 11.)

FIGURE 11. DLC3

Tc = Pin 13
CG = Pin 4



View of Connector Is From Passenger Compartment

- D. After 30 minutes, turn ignition OFF and remove check wire from DLC3
- E. Start the vehicle to confirm successful ECU communication.

NOTE:

If ECU communication is not completed correctly, the engine will not start and DTC B2799 will be set. DTC B2799 will be cleared after engine starts correctly.